
PRE-REQUISITES

Recommended tools







SAFETY

WARNING
The system must not be operated without safety equipment properly mounted.




WARNING At installation, maintenance and service, make sure the motor is shut off.





WARNING Pinch Point

COMPONENTS









Compressed air connection ~6 bar



EC Declaration of IncorporationPartly completed machinery





5112920

FlexLink Components AB SE-41550 Göteborg Sweden

We hereby declare that the following equipment is intended to be incorporated into a FlexLink conveyor system and thereby forming a machine. Operation is prohibited until it has been determined that the machine in which these products are incorporated, has been declared in conformity with the Machinery Directive 2006/42/EC, together with amendments which have entered into force as of the date of issue of this declaration, with particular reference to the essential health and safety requirements in connection with the design, construction and manufacture of the below specified equipment.

Pneumatic stop XMPD 20x10 EA

FlexLink Components AB

Svante Anderholm Chief Operating Officer

Flexlink Components AB

Anders Jonsson Responsible Technical file

FlexLink Components AB

Telephone: +46-31-337 31 00 SE-415 50 Göteborg Fax: +46-31-337 22 33 Sweden www.flexlink.com

ASSEMBLY INSTRUCTION Pneumatic Stop XMPD 20x10 EA

