SAFETY



Power off


Disconnect power


Depressurize


Remove goods

Do not climb!

Inform personnel

WARNING
The system must not be operated without safety equipment properly mounted.

WARNING
Pinch Point

PRE-REQUISITES

Recommended tools



CONTENT



ASSEMBLY INSTRUCTION

Drive unit, direct drive without slip clutch

5112907-07

FlexLink AB
SE-415 50 Göteborg
Sweden
Telephone: +46-31-337 31 00
www.flexlink.com

FLEXLINK
a coesia company



The illustration may not always correspond exactly to ordered component.

SAFETY



Power off


Disconnect power


Depressurize


Remove goods

Do not climb!

Inform personnel

WARNING
The system must not be operated without safety equipment properly mounted.

WARNING
Pinch Point

PRE-REQUISITES

Recommended tools



CONTENT



ASSEMBLY INSTRUCTION

Drive unit, direct drive with slip clutch

5112907-07

FlexLink AB
SE-415 50 Göteborg
Sweden
Telephone: +46-31-337 31 00
www.flexlink.com

FLEXLINK®
a coesia company

1



2



The illustration may not always correspond exactly to ordered component.